



VOLTAGE JUMPER COMBINATIONS

115 VAC	2-8, 3-6, 7-10
120 VAC	2-8, 4-6, 7-11
220VAC	4-8, 7-9
240VAC	4-8, 7-11

- NOTES: (CAUTION)
1. USE BALLY PART NO. E-713 FOR 115-120 VAC.
 2. USE BALLY PART NO. E-713-1 FOR 220-240 VAC.
 3. * INDICATES AID TEST POINT.

TO	J1 PIN	TO	J1 PIN
A4J3-9	1	A4J3-3	11
A4J3-10	2	A2J2-4	15
A4J3-11	3	A3J2-8	16
A4J3-12	4	A2J2-6	17
A4J3-13	5	A2J2-3	18
A4J3-14	6	A4J3-1	19
A4J3-15	7	A3J2-7	20
A4J3-16	8	SPEAKER	9
A4J3-2	10	A8J2-1	12
DOOR PLUG		A8J2-2	13

A7 CABINET ASS'Y. WIRING
NOTE: DIODES ARE IN4004, (E-587-6)

DEPT.	DESCRIPTION	TOOL NO.

REMOVE ALL BARRIERS UNLESS OTHERWISE SPECIFIED APPROVED BY DATE 5-5-87 CHECKED BY DATE 5-5-87 FINISH DATE 5-5-87 HARDENING		Bally MANUFACTURING CORP. 2640 BELMONT AVENUE CHICAGO ILLINOIS #1233	
WIRING DIAGRAM - CABINET FATHOM		DIE SIZE C C FT PER M LBS. PER M. ASSEM NO USED SCALE PART NO W-1186-13 c	